

CLEANLINE CHLOR

Sodium hypochlorite solution for general sanitising of milking equipment.

PRODUCT BENEFITS:

- Contains high levels of chlorine
- Rapid action
- Multi purpose

INSTRUCTIONS FOR USE:

Final Rinse

1. After circulation cleaning use product at 100ml to 100 litres water
2. Draw solution through equipment and run to waste

Main Wash

1. After milking, rinse milking equipment with cold water using at least 10 litres per unit.
2. Make up a 0.4% solution at the rate of 400ml to 100 litres water.
3. Circulate solution for between 7 and 10 minutes.
4. Run to waste.
5. Rinse with clean cold water using at least 10 litres per unit.

SHELF LIFE:

1 year from date of manufacture.

STORAGE:

Store between 0°C to 25°C.

Keep out of direct sunlight.

For health and safety information, please refer to the Safety Data Sheet.



SIZES AVAILABLE:

- P411 – 25 litres
- P412 – 200 litres
- P413 – 1000 litres