

CLEANLINE DX

Concentrated high strength non-foaming chlorine-free circulation powder for the removal of fat and protein deposits in milking equipment using hot water.

PRODUCT BENEFITS:

- Highly effective and concentrated.
- Removes fat and protein deposits.
- Non-foaming, suitable for all water conditions including hard water areas.

INSTRUCTIONS FOR USE:

1. After milking rinse milking equipment with cold water using at least 10 litres per unit.
2. Make a 0.5% dilution (500ml to 100 litres water) at 80°C.
3. Circulate solution for between 7 and 10 minutes or until the water temperature drops to 54°C.
4. Run to waste.
5. Rinse with clean cold water using at least 10 litres per unit.

SHELF LIFE:

1 year from date of manufacture.

STORAGE:

Store between 0°C to 25°C.

Keep out of direct sunlight.

For health and safety information, please refer to the Safety Data Sheet.



SIZES AVAILABLE:

- P251 – 25 litres
- P252 – 200 litres
- P253 – 1000 litres